Heater Spring Avay Pro Auto-Fold Pop Up Net Model# ZPR129QF

Assembly Instructions

IMPORTANT

DO NOT RETURN THIS SPORTS NET TO THE RETAIL STORE WHERE PURCHASED. CALL TOLL FREE: (800) 492-9334

WARNING:


THIS ITEM IS DESIGNED TO POP OPEN AND SNAP CLOSE QUICKLY. DO NOT ALLOW SMALL CHILDREN TO FOLD OR UNFOLD WITHOUT ADULT SUPERVISION! READ WARNING LABELS CAREFULLY.

Never allow anyone to be behind the net in any possible path of the ball should the ball go through the netting. Do not set up the net where property damage could occur if the ball should go through the net. Use common sense, and all the same precautions as you would when playing baseball. Inspect the netting before and during each use. If any rips or holes are found – DO NOT USE! (Note: Nylon cable ties available from any hardware store can be used to repair small holes in the net – be aware of any new holes which may open – and if adequate repairs cannot be made, DO NOT USE!) Batter must wear NOCSAE Approved Batting Helmet. Make sure and disassemble the Spring Away Pro in stormy weather. The net could break or blow over and cause property damage. Make sure area around the sports net is clear of people except for the person using the net. Bodily injury could occur if proper safety precautions are not followed. Use with adult supervision.



95 West 650 South • St. George, Utah 84770 • PH: 800-492-9334 • PH: 435-656-1756 • Fax: 435-688-0741

Parts List






95 West 650 South • St. George, Utah 84770 • PH: 800-492-9334 • PH: 435-656-1756 • Fax: 435-688-0741

Assembly Instructions

 Place Part A (Base Corner Connection) and Parts B (Base Straight Poles) on the ground as shown in Figure 1. Slide Parts B into Part A aligning the push pins and lock in place -Figure 2




 2 - Next take one Part C (Base Support) and insert into Part B locking the push pin in place. Do the same with the other Part C (Base Support) inserting Part C into Part B on the oppisite side
Figure 3

NOTE: Parts C will be pointing upward & outward as seen in Figure 3.

- 3 Carefully unfold Part F (Pop Up Net) and locate the support pockets on the back side of the pop up net. Insert a Part D (Fiberglass Side Pole) into each side pocket on the pop up net - Figure 4.
- 4 After inserting Part D into the side pocket on the pop up net, face the net forward and push the plastic end of Part D into the open steel tube of Part C - Figure 5. Do the same for the both sides.

NOTE: The Spring Away Pro Pop Up Net will lean slightly backwards over the base support.









Figure 4

Figure 5

How To Auto-Fold the Pop Up Net (Refer to Frame Parts Section)








Step 1: Take the Starting Corner (F1) and begin folding toward the Auto Fold Clamp (F2).


Step 2: Insert the Starting Corner (F1) in to the Auto Fold Clamp (F2).

Step 3: Take the Auto Fold Clip (F3) with your right hand, and with your left hand pull the Auto Fold Eyelet (F4) toward the Auto Fold Clip (F3).



Step 4: Snap the Auto Fold Clip (F3) in to the Auto Fold Eyelet (F4).





Step 5: With your right hand, pull the Auto Fold Handle (F5), while pushing the Net (F) towards the ground with your left hand.

Step 6: With the Net (F) fully collapsed, reattach the Auto Fold Handle (F5) to the velcro attachment and place the Net (F) inside the Carrying Bag (G).