

Model# ST49

Read This Before Operating

IMPORTANT

DO NOT RETURN THE BIG LEAGUE MACHINE TO THE RETAIL STORE WHERE PURCHASED. CALL TOLL FREE: (800) 492-9334.

CUSTOMER SERVICE

HEATER SPORTS is dedicated to your customer satisfaction. If you experience any trouble with the operation of the Big League Soft Toss Machine contact us at: (800) 492-9334 or go to our website at www.HeaterSports.com.

BIG LEAGUE BALL RECOMMENDATION

Heater Sports recommends using any Heater Sports lite or real baseballs in your Big League Pro Machine. In addition, you can use regulation baseballs, and any other 9" ball.

WARNING: THIS PRODUCT IS TO BE USED BY ADULTS ONLY. MAKE SURE MACHINE IS TURNED OFF BEFORE ASSEMBLY! KEEP HANDS AND ALL BODY PARTS AWAY FROM BALL ENTRY AND EXIT! SERIOUS INJURY MAY OCCUR IF USED INCORRECTLY!

- Please be sure to read all of the instructions before using the Big League Soft Toss Machine to ensure the machine is working properly.
- Parents: Your child should be made aware of potential dangers when using any electrical powered product.
- Never put your fingers into the Big League while it is operating.
- The Big League is not a toy and an adult should supervise children. It is very important that the batter make sure the area is clear before swinging bat.
- Stay clear of the ball opening while the Big League is operating. Children should be advised of any danger and appropriate precautions should be taken.



95 West 650 South • St. George, Utah 84770 PH: 800-492-9334 • PH: 435-656-1756 Fax: 435-688-0741




BIG LEAGUE ASSEMBLY INSTRUCTIONS

STEP 1: Locate Part (A) and insert Parts (B) into the tripod base as shown. (*Make sure the push-pins insert into the tripod base and lock.*)

STEP 2: Insert Top Pole #1 (C) into top of tripod (A) and then Top Pole #2 (D) into Top Pole #1 (C) (*Make sure the push-pins insert into each section and lock.*)







BIG LEAGUE ASSEMBLY INSTRUCTIONS (Continued)

STEP 3: Take Part (E) and push it onto Part (D) base as shown.

STEP 4: Push Part (F) onto Part (E) by aligning the notches and pushing down firmly. Do the same for Part (G) onto Part (F) as shown.





STEP 5: Insert the Ball Ramp Part (H) into the holes where - the balls exit the spiral on Part (E).

STEP 6: Plug the Ball Feeder wire from Part (D) into the smaller socket on the back of Part (F). Plug the Power Adapter into the larger socket on the front on Part (F).



(Ball Feeder Power Socket)




(Power Adapter Socket)

Do not use any A/C Plug Adapter other than the one provided with the Big League.

8 hour battery packs are available to turn your Big League into a portable battery operated machine.

Make Your Big League Battery Operated

Call **1-800-492-9334** to order an 8 hour battery pack for your Big League Soft Toss Machine.




95 West 650 South • St. George, Utah 84770 PH: 800-492-9334 • PH: 435-656-1756 Fax: 435-688-0741

BIG LEAGUE OPERATION INSTRUCTIONS

Balls: The Big League will use any regulation sized ball. ——— Heater Sports recommends Slider Synthetic Leather Lite-Balls, Slider Soft Lite-Balls, or Heater Baseballs

Power: The Big League Power Adapter will plug into any standard wall outlet. After connecting the Big League to electric or battery power, turn on the machine with the power switch located on the side of Part (F).

The Big League will also run on battery power. There is an 8 Hour 6 Volt Rechargeable Battery available (Model# CR25, sold separately), which connects and sits inside the Big League.



Make Your Big League Battery Operated Call **1-800-492-9334** to order an 8 hour battery pack for your Big League Soft Toss Machine.

WARNING!

Stay clear of ball exit when machine is operating. Keep hands and fingers clear of motor operation. Use under adult supervision only.





95 West 650 South • St. George, Utah 84770 • PH: 800-492-9334 • PH: 435-656-1756 • Fax: 435-688-0741