

OWNER'S MANUAL

Xtender[®] 24' Batting Cage

Model No. XT299

Serial No. _____

Serial number found on warning label sewn onto netting.

www.HeaterSports.com


ACTIVATE YOUR WARRANTY

To register and activate your 1 year parts & labor warranty, call 1-800-492-9334

CUSTOMER CARE

For customer service inquiries, please call our toll free line at 1-800-492-9334.

Read all precautions and instructions in this manual before using this product. Keep this manual for future reference.



DO NOT RETURN TO STORE, CALL 1-800-492-9334

READ BEFORE ASSEMBLING

IF YOU EXPERIENCE ISSUES WITH THIS CAGE, DO NOT RETURN TO THE RETAIL STORE WHERE PURCHASED - CALL TOLL FREE: (800) 492-9334

WARNING

> DO NOT LEAVE CAGE ASSEMBLED DURING ANY WIND, RAIN, OR SNOW. FAILURE TO DO SO CAN VOID WARRANTY.

> Adult supervision required AT ALL TIMES during use.

> ALWAYS inspect netting before and during use. If any rips or holes appear - DO NOT USE! Serious bodily injury and/or property damage could occur.

> Make sure Pitching Machine is turned off and unplugged when attaching the Batting Cage Net Harness Tubes to the Pitching Machine (If cage has net harness).

> Never allow a batter in the Batting Cage until the Pitching Machine has been sighted in and pitching at the desired target and desired speed. Only one batter in the cage at a time.

> Machine operator must remain behind Pitching Machine at all times while Machine is in use. Being too close to the net could cause bodily harm.

WARNING

> If personally pitching inside, a protective screen must be used to protect person throwing balls.

> Batter must wear NOCSAE Approved Batting Helmet.

> Make sure area outside Batting Cage is clear. Net will have slack and may extend outward when hit by an object or ball. Therefore, make sure any person, pet, object or property are clear of this area to prevent bodily injury/property damage.


> Do not use golf balls or similar sized balls inside Net. Failure to do so could allow the balls to break through the Net holes and cause harm.

> Bodily injury could occur if precautions aren't followed. Use common sense and all the same precautions as you would when playing baseball or softball.

> It is recommended to replace this net every year.

PARTS LIST


*Replacement Parts Available by Calling Heater Sports at 1-800-492-9334




STAKE ASSEMBLY

STEP 1: Using a rubber mallet or hammer, pound Ground Stakes (A) into ground as outlined below. For shorter lengths, simply alter the distance as needed.

IMPORTANT: GROUND STAKES HAVE A PUSH PIN ON 1 SIDE. MAKE SURE THE PUSH PIN IS FACING AWAY FROM THE CAGE!




ARCH ASSEMBLY




STEP 2: Go to the middle arch and tie 2 Black Guide Ropes (H) to each metal fiberglass rod fitting as shown below. Then, attach the other side of each rope to the corresponding metal fitting on arches 1 and 3. Finally, attach Part I White Support Rope & Stake (4x) to fittings shown below.

IMPORTANT: Attach Rope to the Actual Fiberglass Rod fitting, not the smaller metal arch welded on the fitting.



STEP 3: Attach remaining 4 Black Guide Ropes to the Angled Metal Pole (D) Foam Padding.

Next, Unfold the Batting Cage Net (J) and spread the net over the length of the cage frame.




STEP 4: Starting with the middle arch, grab one B pole and someone else grab the other B pole. Together, carefully raise the poles and slide over the middle ground stakes (See Fig. 1). **Make sure the ground stake push-pin locks in the metal pole hole!** Repeat this for the remaining 2 arches so the cage stands upright.

Next, spread the netting evenly over the frame so there is equal parts netting touching all sides of the ground surrounding the cage.


Finally, Locate the fiberglass rod fitting where the White Support Rope is attached and select 1 hole in the netting. Push the support stake through this hole so the white ropes and 4 support stakes are outside the cage, then stake each one in the ground slightly wider than the width of the cage.

NOTE: The cage should look like the image below. You may need to loosen/tighten Cage or support ropes to tweak the angle of the arches.



ATTACHING MACHINE TO HARNESS (OPTIONAL)

STEP 1:



Batting Cage Net Harness Tubes

OPTIONAL ACCESSORY (Sold

Separately): You can purchase any Heater Sports Pitching Machine product to attach to the Xtender Home Batting Cage. Call Toll Free: 1-800-492-9334 to locate a retail store near you.

WARNING


Make sure Heater Sports Pitching Machine is turned off and unplugged when attaching Batting Cage Net Harness Tube to Heater Sports Pitching Machine.

WARNING!


- Never allow a batter in the Batting Cage until the Heater Sports Pitching Machine has been sighted in and pitching at the desired target and at the right speed.
- Make sure Heater Sports
 Pitching Machine is turned
 off and unplugged when
 attaching the Batting Cage Net
 Harness Tube to the Heater
 Sports Pitching Machine.
- Make sure and disassemble the Xtender Batting Cage in stormy weather. The cage could break or blow over and cause property damage.
- Make sure area around batting cage is clear of people except for batter and machine operator. Bodily injury could occur if proper safety precautions aren't followed.

JOINING 2 CAGES (IF APPLICABLE)

STEP 1: Fully assemble both batting cages and place them end-to-end 2 to 4 inches apart.



STEP 2: Match the red reinforced seams together where the cages meet. Using the extra support ropes weave the two cages together.



STEP 3: Using scissors, cut an opening in the netting where the stitched netting come together on both cages.

STEP 4: After cutting the netting on both cages take the extra netting and attach it to the end of the cage opposite the Pitching Machine Harness. This extra netting will provide additional support and cushioning to the backstop area.

