


### Parts List


#### SHORT POLE

- A: Bottom Pole  
B: Top Pole  
C: Stake With 3' Rope (2x)




#### ROPE LINE COMPONENTS

- D: 25' Rope Line  
E: Height Adjustment Ball  
F: Metal O-Ring  
G: Nylon Strap & Baseball  
H: Shock Absorber Ball



#### TALL POLE


- I: Bottom Pole  
J: Middle Pole (4x)  
K: Top Pole  
L: Stake With 12' Rope (2x)



### Exploded View Assembly

**STEP 1:** Locate a spot in your desired area approximately 12' wide x 30' long. You may alter as your space allows.

**STEP 2:** Assemble Hit Line as shown in Assembly Drawing below.



## How To Use


**STEP 1:** Read all warning labels before using Hit Line to ensure safety is followed (See below).

**STEP 2:** Move Height Adjustment to desired position by sliding up or down the rope line (See figure 1). The correct height will be where the baseball is about waist high for batter.

**STEP 3:** Swing and hit baseball to move it up the rope line. Depending on force of swing, ball may hit the Shock Absorber Ball and gently move back down the rope line to its original position. Repeat swinging to perfect your hand-eye coordination.

**TIP:** To simulate a moving pitch, hit the ball as it travels back down the line.

**Figure 1.**  
**Height Adjustment**



## Warnings

**Heater<sup>®</sup>**  
**HIT LINE<sup>™</sup>**

### WARNING

- **IMPROPER USE OF THE HIT LINE CAN RESULT IN SERIOUS BODILY INJURY. THIS IS NOT A TOY.**
- Hit Line must be properly set up by an adult older than 18 years old. Adult supervision is required.
- Always use the Hit Line in an area away from foot traffic. Nothing should obstruct the batter or device when in use. Make sure others stay clear of the batting zone and ball travel path.
- Make sure there is adequate space to use the Hit Line safely. A ten foot safety zone around the batter is recommended.
- To avoid strangulation & other bodily injuries, keep children, adults, and pets away from ropes.

**Model# LD59BB**  
**1-800-492-9334**

**Heater<sup>®</sup>**  
**HIT LINE<sup>™</sup>**

### WARNING

- Always inspect the Hit Line before using. Do not use your Hit Line if it appears to be damaged. If anything appears to be damaged, please call customer service (1-800-492-9334).
- Always wear a NOCSAE approved helmet, recommended with a face guard. If ball or lanyard is hit improperly it can spin and hit you in the face or other bodily parts.
- The natural effects of friction from ball movement and bat contact with the cord will cause the cord to wear. Discontinue use at the first sign of excessive cord fraying.
- When not in use, Hit Line should be properly stored with cords wrapped and securely away from children and pets.

**Heater<sup>®</sup>**  
**SPORTS**


**Hit Line<sup>™</sup> Baseball**  
**Swing Trainer**  
**Model# LD59BB**

**IMPORTANT**  
**DO NOT RETURN WHERE**  
**PURCHASED. CALL TOLL FREE:**  
**(800) 492-9334.**

For questions, call: 1.800.492.9334  
Online: [www.HeaterSports.com](http://www.HeaterSports.com)  
Email: [MoreInfo@HeaterSports.com](mailto:MoreInfo@HeaterSports.com)

# HIT LINE ADDENDUM 1

## Rope Line Tensioner



The rope line is designed to be tight so the ball flows up and down smoothly; however, it's natural for the rope line to stretch and lose tension after many hits.

To ensure the rope line stays tight, we have provided a Rope Line Tensioner. Simply rotate the tensioner to add more tightness to the rope line whenever the rope line becomes loose.